

# NPort 6150/6250 Series Quick Installation Guide

---

Edition 9.0, November 2016

## Technical Support Contact Information [www.moxa.com/support](http://www.moxa.com/support)

### Moxa Americas:

Toll-free: 1-888-669-2872

Tel: 1-714-528-6777

Fax: 1-714-528-6778

### Moxa China (Shanghai office):

Toll-free: 800-820-5036

Tel: +86-21-5258-9955

Fax: +86-21-5258-5505

### Moxa Europe:

Tel: +49-89-3 70 03 99-0

Fax: +49-89-3 70 03 99-99

### Moxa Asia-Pacific:

Tel: +886-2-8919-1230

Fax: +886-2-8919-1231

### Moxa India:

Tel: +91-80-4172-9088

Fax: +91-80-4132-1045



© 2016 Moxa Inc. All rights reserved.

P/N: 1802061500016



## Overview

The NPort 6150/6250 series secure serial device servers provide reliable serial-to-Ethernet connectivity for a wide range of serial devices. The NPort 6150/6250 support TCP Server, TCP Client, UDP, and Pair-Connection operation modes to ensure the compatibility of network software. In addition, the NPort 6150/6250 also support Secure TCP Server, Secure TCP Client, Secure Pair-Connection, and Secure Real COM modes for security critical applications such as banking, telecom, access control, and remote site management.

## Package Checklist

Before installing a NPort 6150/6250 secure device server, verify that the package contains the following items:

- 1 NPort 6150 or NPort 6250
- Power adapter (does not apply to -T models)
- 2 wallmount ears
- Documentation and software CD
- Quick installation guide (this guide)
- Warranty card


### Optional Accessories

- DK-35A: DIN-rail mounting kit (35 mm)
- DIN-rail power supply
- CBL-RJ45M9-150: 8-pin RJ45 to male DB9 cable
- CBL-RJ45M25-150: 8-pin RJ45 to male DB25 cable


NOTE: Please notify your sales representative if any of the above items are missing or damaged.

## Hardware Introduction

### NPort 6150



## NPort 6250




**Reset Button**—Press the Reset Button continuously for 5 sec to load factory defaults. Use a pointed object, such as a straightened paper clip or toothpick, to press the reset button. This will cause the Ready LED to blink on and off. The factory defaults will be loaded once the Ready LED stops blinking (after about 5 seconds). At this point, you should release the reset button.

### LED Indicators

| LED Name | LED Color | LED Function                                   |  |
|----------|-----------|--|--|
| PWR      | Red       | Power is being supplied to the power input.    |  |
| Ready    | Red       | Steady on                                      | Power is on and the NPort is booting up.   |
|          |           | Blinking                                       | Indicates an IP conflict, or, the DHCP or BOOTP server did not respond properly or a relay output occurred. Check the relay output first. If after resolving the relay output the RDY LED is still blinking, then there is an IP conflict, or the DHCP or BOOTP server did not respond properly. |
|          | Green     | Steady on                                      | Power is on and the NPort is functioning normally.   |
|          |           | Blinking                                       | The device server has been located by the Administrator's Location function.   |
|          | Off       | Power is off, or power error condition exists. |  |

| LED Name          | LED Color | LED Function  |
|-------------------|-----------|---|
| Link              | Orange    | 10 Mbps Ethernet connection                                       |
|                   | Green     | 100 Mbps Ethernet connection                                      |
|                   | Off       | Ethernet cable is disconnected, or has a short.                   |
| P1, P2            | Orange    | Serial port is receiving data.                                    |
|                   | Green     | Serial port is transmitting data.                                 |
|                   | Off       | No data is being transmitted or received through the serial port. |
| P1, P2 in-use LED | Green     | Serial port was opened by server side software.                   |
|                   | Off       | Serial port has not been opened by server side software.          |

## Adjustable pull high/low resistor for RS-422/485 (150 K $\Omega$ or 1 K $\Omega$ )




Jumpers are used to set the pull high/low resistors. The default is 150 k $\Omega$ . Short the jumpers to set this value to 1 k $\Omega$ . Do not use the 1 k $\Omega$  setting with RS-232 mode, since doing so will degrade the RS-232 signals and shorten the communication distance.

## Hardware Installation Procedure

- STEP 1:** Connect the 12-48 VDC power adaptor to the NPort 6150 and then plug the power adaptor into a DC outlet.
- STEP 2:** For first-time configuration, use a cross-over Ethernet cable to connect the NPort 6150 directly to your computer's Ethernet cable. For connecting to a network, use a standard straight-through Ethernet cable to connect to a hub or switch.
- STEP 3:** Connect the NPort 6150's serial port to a serial device.

## Placement Options

The NPort 6150/6250 can be placed flat on a desktop or other horizontal surface. In addition, you may use the DIN-rail or wallmount options, as illustrated below.




## Software Installation Information

The Documentation and software CD contains the user's manual, NPort Search Utility, and the PComm Lite Suite. Insert the CD into your computer's CD-ROM drive and follow the on-screen instructions. Please refer to the user's manual for additional details on using the NPort Search Utility and PComm Lite.

## Pin Assignments and Cable Wiring

### RS-232/422/485 Pin Assignment (male DB9)

| Pin | RS-232 | RS-422<br>4-wire RS-485 | 2-wire<br>RS-485 |
|-----|--------|-------------------------|------------------|
| 1   | DCD    | TxD- (A)                | –                |
| 2   | RXD    | TxD+ (B)                | –                |
| 3   | TXD    | RxD+ (B)                | Data+ (B)        |
| 4   | DTR    | RxD- (A)                | Data- (A)        |
| 5   | GND    | GND                     | GND              |
| 6   | DSR    | –                       | –                |
| 7   | RTS    | –                       | –                |
| 8   | CTS    | –                       | –                |
| 9   | –      | –                       | –                |



Two serial cables for connecting the NPort 6150 to a serial device can be purchased separately. The wiring diagrams for the two cables are shown below.

## Specifications

| LAN                             |   |
|---------------------------------|---|
| Ethernet                        | NPort 6150/6250: 10/100 Mbps, RJ45<br>NPort 6250-S-SC: Single-mode fiber<br>NPort 6250-M-SC: Multi-mode fiber |
| Protection                      | Built-in 1.5 kV magnetic isolation  |
| Serial                          |   |
| No. of ports                    | NPort 6150: 1<br>NPort 6250: 2  |
| Interface                       | RS-232/422/485 (male DB9)   |
| Serial Communication Parameters |   |
| Parity                          | None, Even, Odd, Space, Mark  |
| Data bits                       | 5, 6, 7, 8  |
| Stop bit(s)                     | 1, 1.5, 2   |
| Flow control                    | RTS/CTS, XON/XOFF, DTR/DSR  |
| Speed                           | 50 bps to 921.6 kbps (supports nonstandard baudrates)   |
| Console Port                    | RS-232 (please see the User's Manual for detailed operating instructions)                                     |
| Memory                          | One SD socket   |
| Software Features               |   |
| Protocols                       | ICMP, IPv4/v6, TCP, UDP, DHCP, BOOTP, Telnet, DNS, SNMP, HTTP, SMTP, HTTPS, SSL, SSH, PPPoE, RFC2217          |
| Utilities                       | Device Search Utility for Windows   |
| Security Protocols              | SSLv3, TLSv1.0/1.1/1.2  |

|                                  |   |
|----------------------------------|---|
| OS Driver Support                | Windows Real COM Drivers: Windows 95/98/ME/NT/2000, Windows XP/2003/Vista/2008/7/8/8.1/10 (x86/x64), Windows 2008 R2/2012/2012 R2 (x64), Windows Embedded CE 5.0/6.0, Windows XP Embedded<br>Fixed TTY Drivers: SCO Unix, SCO OpenServer, UnixWare 7, QNX 4.25, QNX 6, Solaris 10, FreeBSD, AIX 5.x, HP-UX 11i, Mac OS X<br>Linux Real TTY Drivers: Linux 2.4.x, 2.6.x, 3.x<br>Management: SNMP MIB-II<br>IP Routing: Static, RIP-I, RIP-II |
| Configuration                    | Web Console, Serial/Telnet Console, Windows utility   |
| <b>Power Requirements</b>        |   |
| Power input                      | 12 to 48 VDC  |
| <b>Mechanical Specifications</b> |   |
| Material                         | Aluminum (1 mm)   |
| <b>Environmental Limits</b>      |   |
| Operating Temperature            | Standard models:<br>NPort 6150/6250 series:<br>0 to 55°C (32 to 131°F)<br>Wide temp. models:<br>NPort 6150-T/6250-T series:<br>-40 to 75°C (-40 to 167°F)   |
| Storage Temperature              | Standard models:<br>NPort 6150/6250 series:<br>0 to 55°C (32 to 131°F)<br>Wide temp. models:<br>NPort 6150-T/6250-T series:<br>-40 to 75°C (-40 to 167°F) ,<br>5 to 95% RH  |
| <b>Regulatory Approvals</b>      |   |
| EMC                              | FCC Class A, CE Class A   |
| Safety                           | UL, CUL, TÜV  |