

ZeFit²

ENGLISH

CHARGING	05	SLEEP	11
PAIRING	06	GOALS	12
WEARING	80	REMINDERS	12
DISPLAY	09	NOTIFICATIONS	13
ACTIVITY	10	TECH SPECS	14

OVFRVIFW



To interact with ZeFit² touchscreen, double tap on the touch-sensitive area. ZeFit² touchscreen only respond to tap gestures in this specific touch-sensitive area. ZeFit² screen turns off when not in use. Double tap the touch area to wake the device. To ensure ZeFit² is responding accurately to your taps, we recommend using your fingertip and not your nail. To move between screens, swipe left or right

1. CHARGING



Charge ZeFit² for two hours before your first use.

1. Put ZeFit² on the magnetic charging dock

 Make sure the pin on the charging dock fit correctly onto the charging terminals on the back of ZeFit²

Plug the small end of the USB cable provided into the charging's dock USB port

4. Plug the big end of the USB cable into a power source

 A battery indicator will fill to indicate charging is in progress. Once ZeFit² is charged, the battery indicator will be full



A full charge takes 1:30 hour. When the battery level gets low, a battery indicator will appear.

2. PAIRING

The first time you use ZeFit², a SET UP message will prompt you to set up your ZeFit² using a mobile device or a computer.

GET ZeFit² APP

To set up your ZeFit² using your mobile device, you first need to get ZeFit² App. Search for ZeFit² App in the App store, Google Play or Windows Phone store, download and install the App on your mobile device.









System Requirements				
iOs	Android	Windows Phone		
iOS 7+ devices with Bluetooth 4.0 BLE iPhone 4s, 5, 5c, 5s, 6, 6 Plus, iPad (3 st , 4 th and 5 th gen) iPad Mini, iPod touch (5 th gen)	Select Android 4.3 + devices that support Bluetooth 4.0 BLE	Select Windows Phone 8.1 that support Bluetooth 4.0 BLE		

Visit www.mykronoz.com to get the latest compatibility list

Enable Bluetooth on your mobile device

ZeFit² to pair a new device

- 2. Open ZeFit² App on your mobile device. Sign up if you are a new member or Log in with your existing account. After entering your personal information, tap Set up
- 3. Make sure ZeFit² is nearby and select ZeFit² in the list of devices
- 4. You will receive a pairing request on your mobile device. Press Pair to accept it
- 5. Then, a pairing request will appear on your ZeFit² display
 Tap on your ZeFit² to accept the pairing
- 6. When ZeFit² is successfully paired, you will be notified on ZeFit² and on your mobile device's screen



You can also set up your ZeFit² using our Mac or PC software available on MyKronoz website: http://www.mykronoz.com/support/

System requirements: Windows 7,8, XP - Mac OS X 10.8 and above

If pairing fails, repeat the same steps. Pairing is a one-time process. If you want to pair ZeFit² with another account, you first need to unpair it from the current one. Open ZeFit² App, go to Settings > Connect ZeFit² > Unpair ZeFit². Tap Connect

3. WFARING



ZeFit² has a removable wristband and is adjustable to fit different wrist sizes.

- Pop ZeFit² tracker unit into the wristband
- Place ZeFit² around your wrist and put the clasp pin inside the hole
- 3. Press a few times to ensure the pin is fully inserted and that ZeFit² is securely fastened

To get the most accurate data, we recommend wearing ZeFit² on your non-dominant hand and not too loose.

3. DISPLAYS



ZeFit? will automatically sync the time and date of your paired mobile device. You can set your preferred time and date format manually in the Settings tab of ZeFit? App. Make sure you keep the device charged to avoid the time being reset

4. ACTIVITY

ZeFit² tracks the number of steps taken, distance travelled and calories burned throughout the day. You can view your daily activity in real-time on ZeFit² display by swiping left or right on the touchscreen.



You can also monitor your activity data and history from the Activity tab of ZeFit². On the main activity screen, you can check your performance level against your daily goals. Click on any activity bar to get a detailed graph of your daily, weekly and monthly performance.



ZeFit² shows daily data. The activity tracker resets at midnight. To upload your latest activity data, do not forget to tap the sync icon in the upper right hand corner of ZeFit² App

5. SLEEP

ZeFit² tracks the hours slept and the quality of your sleep (light sleep, deep sleep, awake times)

■ START / EXIT SLEEP MODE

To start sleep mode, open ZeFit² App, tap on the bottom purple sleep bar, click on Add sleep log > Start Sleep now
To end sleep mode, open ZeFit² App, tap on the bottom purple sleep bar, click on Add sleep log > Awake

■ PRESET SLEEP

Open ZeFit² App > Go to Settings > Advanced Settings > Click on Preset sleep to enter your desired bed and wake up times. By default, ZeFit² will track your sleep from 11pm until 7am.

To upload your latest sleep data, do not forget to tap the sync icon in the upper right hand corner of ZeFit² App. If you forgot to activate sleep mode, you can manually add sleep logs in ZeFit² App. Open ZeFit² App, click on Add sleep log > Add sleep

6. GOALS

Tap the Goals tab of ZeFit² App to set daily goals for steps taken, distance travelled, calories burned and hours slept. Click on the sync button in the upper right corner to save your goals. On the Steps screen of your ZeFit², a progress bar will show how close you are to your daily goal.

Once you hit one of your daily goal, ZeFit² will gently vibrate and display a Goal achieved icon



7. REMINDERS

Tap the Reminders tab of ZeFit² App to add daily life reminders. You can set up to 6 daily reminders, and choose the type of reminder and preferred time and day. ZeFit² will gently vibrate and display the corresponding reminder icon to alert you. A single tap on your ZeFit² can dismiss the reminder. If not dismissed, the same alert will repeat after two minutes.

8. NOTIFICATIONS

ZeFit² shows notifications of incoming and missed calls, SMS, email, social media activity, calendar events and anti-lost alert*. Open ZeFit² App, tap Settings > Notifications to select the notifications you want to receive onto your ZeFit². If you wish to disable certain notifications, swipe the selection button to the left. A single tap on your ZeFit² can dismiss the notification. If not dismissed, the notification will reappear next time you wake up the screen.

Setting up notifications for iOS users:

- Go to "Settings" of your iOS device
- Tap "Notification Center"
 Select which type of notifications you wish to receive on ZeFit²
- Enable "Show in Notification Center" to receive the notification on ZeFit²



Caller ID supports latin character only. For more languages support, please contact support@mykronoz.com. *Windows Phones may not support those features, please contact support@mykronoz.com.for more information.

9. TECH SPECS

Size & Circumference	48 x 20 x 9.3 mm
	Min: 159 mm
	Max: 194 mm
Weight	21.5 g
Bluetooth	4.0 BLE
Bluetooth operating range	Up to 5 meters
Battery type	55 mAh
Battery life	Up to 5 days
Charging time	2 hours
Memory	5 days of activity
Display	Touchscreen OLED 128*32 pixel
Sensor	3-axis accelerometer
Operating temperature	-20°C to +40°C
Water resistance	IP67
International warranty	1 year